


COUNTERTOP ICE MAKER

IMD Series - Installation Manual



Release Date: March 12, 2004

Publication Number: 638085277INS

Revision Date: February 10, 2015

Revision: F

Visit the Cornelius web site at www.cornelius.com for all your Literature needs.

The products, technical information, and instructions contained in this manual are subject to change without notice.

These instructions are not intended to cover all details or variations of the equipment, nor to provide for every possible contingency in the installation, operation or maintenance of this equipment. This manual assumes that the person(s) working on the equipment have been trained and are skilled in working with electrical, plumbing, pneumatic, and mechanical equipment. It is assumed that appropriate safety precautions are taken and that all local safety and construction requirements are being met, in addition to the information contained in this manual.

This Product is warranted only as provided in Cornelius' Commercial Warranty applicable to this Product and is subject to all of the restrictions and limitations contained in the Commercial Warranty.

Cornelius will not be responsible for any repair, replacement or other service required by or loss or damage resulting from any of the following occurrences, including but not limited to, (1) other than normal and proper use and normal service conditions with respect to the Product, (2) improper voltage, (3) inadequate wiring, (4) abuse, (5) accident, (6) alteration, (7) misuse, (8) neglect, (9) unauthorized repair or the failure to utilize suitably qualified and trained persons to perform service and/or repair of the Product, (10) improper cleaning, (11) failure to follow installation, operating, cleaning or maintenance instructions, (12) use of "non-authorized" parts (i.e., parts that are not 100% compatible with the Product) which use voids the entire warranty, (13) Product parts in contact with water or the product dispensed which are adversely impacted by changes in liquid scale or chemical composition.

Contact Information:

To inquire about current revisions of this and other documentation or for assistance with any Cornelius product contact:

www.cornelius-usa.com

800-238-3600

Trademarks and Copyrights:

This document contains proprietary information and it may not be reproduced in any way without permission from Cornelius.

This document contains the original instructions for the unit described.

CORNELIUS INC
101 Regency Drive
Glendale Heights, IL
Tel: + 1 800-238-3600

Printed in U.S.A.

TABLE OF CONTENTS

Safety Instructions	1
Read and Follow ALL Safety Instructions	1
Safety Overview	1
Recognition	1
Different Types of Alerts	1
Safety Tips	1
Qualified Service Personnel	1
Safety Precautions	2
Shipping And Storage	2
General Information	3
Specification Chart	3
Installation Instructions	5
Remove Ice maker from Carton	5
Cabinet Removal	5
Preparation of Installation Site	5
Water Inlet Hook-up	5
Electrical Supply	6
Drain Connection	6
Auger Engagement	7
Initial Start Up, Checks & Adjustment Instructions	7
Guide To Service	8
Ice maker Cleaning and Sanitizing Procedures	8
Maintenance	8
Monthly	8
Quarterly	8
Semi-Annually	9
Water Level Control	10
How Water Level Control Works	10
Purpose of Water Level Control	10
To Replace Water Level Control	10
To Replace Water Level Safety Switch	10
Ice Level Control	11
Refrigeration System Adjustments	11
Expansion Valve	11
Adjustment and Troubleshooting	11
Gear Motor	13
Shaft Seal Installation and Replacement	13

Auger & Extruding Head Removal	14
Installation and Shaft Seal Replacement	14
Upper Nut and Bearings	14
To Replace Bearings	15
Troubleshooting Compressor	15
Electrical Checkout	15
Overload Check	16
Compressor Check	16
Capacitor Check	16
Troubleshooting Gear Motors	16
The Gear motor will not run	16
The Gear motor Starts but Trips Repeatedly on the Overload Protector	16
The Motor Runs but Output Shaft does not Rotate	17
Overload Check	17
Motor Check	17
Safety Controls	18
Guide To Good Ice	19
Schematics	20

SAFETY INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

Safety Overview

- Read and follow **ALL SAFETY INSTRUCTIONS** in this manual and any warning/caution labels on the unit (decals, labels or laminated cards).
- Read and understand ALL applicable OSHA (Occupational Safety and Health Administration) safety regulations before operating this unit.

Recognition

<i>Recognize Safety Alerts</i>
 <i>This is the safety alert symbol. When you see it in this manual or on the unit, be alert to the potential of personal injury or damage to the unit.</i>

DIFFERENT TYPES OF ALERTS



DANGER:

Indicates an immediate hazardous situation which if not avoided **WILL** result in serious injury, death or equipment damage.



WARNING:

Indicates a potentially hazardous situation which, if not avoided, **COULD** result in serious injury, death, or equipment damage.



CAUTION:

Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury or equipment damage.

SAFETY TIPS

- Carefully read and follow all safety messages in this manual and safety signs on the unit.
- Keep safety signs in good condition and replace missing or damaged items.
- Learn how to operate the unit and how to use the controls properly.
- **Do not** let anyone operate the unit without proper training. This appliance is **not** intended for use by very young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
- Keep your unit in proper working condition and do not allow unauthorized modifications to the unit.

QUALIFIED SERVICE PERSONNEL



WARNING:

Only trained and certified electrical, plumbing and refrigeration technicians should service this unit. **ALL WIRING AND PLUMBING MUST CONFORM TO NATIONAL AND LOCAL CODES. FAILURE TO COMPLY COULD RESULT IN SERIOUS INJURY, DEATH OR EQUIPMENT DAMAGE.**



SAFETY PRECAUTIONS

This unit has been specifically designed to provide protection against personal injury. To ensure continued protection observe the following:



WARNING:

Disconnect power to the unit before servicing following all lock out/tag out procedures established by the user. Verify all of the power is off to the unit before any work is performed.

Failure to disconnect the power could result in serious injury, death or equipment damage.



CAUTION:

Always be sure to keep area around the unit clean and free of clutter. Failure to keep this area clean may result in injury or equipment damage.

SHIPPING AND STORAGE



CAUTION:


Before shipping, storing, or relocating the unit, the unit must be sanitized and all sanitizing solution must be drained from the system. A freezing ambient environment will cause residual sanitizing solution or water remaining inside the unit to freeze resulting in damage to internal components.

GENERAL INFORMATION

SPECIFICATION CHART

Models	Condensing Unit	VAC	Hz	Ph	Comp RLA	Fan Amps	Grmtr Amps	Refrigerant		Circuit Fuse
								Oz.	Type	
IMD300-15A	Air Cooled	115	60	1	6	0.82	2	12	R134a	15
IMD302-15A	Air Cooled	220/240	50	1	3	.5	1.6	12	R134a	15
IMD300-30A	Air Cooled	115	60	1	10.5	1	2	25	R404A	20
IMD300-30W	Water Cooled	115	60	1	10.1	N/A	2	13	R404A	20
IMD301-30A	Air Cooled	208/230	60	1	5.7	1	1.6	28	R404A	20
IMD301-30W	Water Cooled	208/230	60	1	5.7	N/A	1.6	13	R404A	20
IMD302-30A	Air Cooled	220/240	50	1	5.3	0.5	1.6	28	R404A	20
IMD302-30W	Water Cooled	220/240	50	1	5.3	N/A	1.6	13	R404A	20
IMD600-30A	Air Cooled	115	60	1	14.6	1	2	25	R404A	20
IMD600-30W	Water Cooled	115	60	1	12	N/A	2	14	R404A	20
IMD601-30A	Air Cooled	208/230	60	1	7.7	1	1.6	28	R404A	20
IMD601-30W	Water Cooled	208/230	60	1	7.7	N/A	1.6	14	R404A	20
IMD602-30W	Water Cooled	220/240	50	1	8.2	N/A	1.6	14	R404A	20
IMD600-90A	Air Cooled	115	60	1	14.6	1	2	20	R404A	25
IMD600-90W	Water Cooled	115	60	1	12	N/A	2	14	R404A	20
IMD601-90A	Air Cooled	208/230	60	1	7.7	1	1.6	24	R404A	20
IMD601-90W	Water Cooled	208/230	60	1	7.7	N/A	1.6	14	R404A	20
IMD602-90A	Air Cooled	220/240	50	1	8.2	0.5	1.6	24	R404A	20
IMD602-90W	Water Cooled	220/240	50	1	8.2	N/A	1.6	14	R404A	20

NOTE: For Units Not Listed in Above Chart, Refer to Nameplate or contact Factory Service.



SHIPPING WT. 189 LBS. (APPROX.)

Figure 1. Dimension Drawing (15 lb.) IMD 300-15




Figure 2. Dimension Drawings (30 lbs.) IMD 300-30 and IMD 600-30




Figure 3. Dimension Drawings (90 lbs.) IMD 600-90

INSTALLATION INSTRUCTIONS

REMOVE ICE MAKER FROM CARTON

1. Keep unit in the upright position, remove carton and pallet from unit and inspect unit for damage. Upon inspection of unit, if any damage is found, file a claim with carrier immediately.
2. Locate Startup Card either on outside of container or on plastic liner. Fill in proper information and send one copy to factory, and other copy to Distributor. Postage is prepaid.

CABINET REMOVAL

1. Locate and remove the (2) screws from under the front cover. Lift cover forward and up to remove.
2. Lift up front edge of top cover. Slide back about 1/2 inch and remove.
3. Remove (6) screws from the front of the machine.
4. Remove side panels by sliding the front edge out and then back slightly to disengage.
5. Remove the front splash panel by lifting slightly to disengage the front, then tilt forward and remove.
6. Remove bin top and remove shipping insert.

PREPARATION OF INSTALLATION SITE

The refrigeration system on air cooled units requires airflow, so a well ventilated area should be chosen.

1. In general a minimum of 6 inches must be maintained, free of any obstruction, for air intake. A minimum of 4 inches clearance is required for air exhaust.
2. For IMD600-30A, a minimum of 6 inches must be maintained, free of any obstruction, for air intake. A minimum of 4 inches clearance is required at sides and 12 inches on top for air exhaust.
3. For IMD300-30A, a minimum of 6 inches must be maintained, free of any obstruction, for air intake. A minimum of 4 inches clearance is required at sides and top for air exhaust.
4. With template provided make the necessary provisions in the counter for water, drain and the electrical hook-up. Provisions are available for rear and bottom connections of water and electrical. Use hole plugs provided to plug unused holes.

WATER INLET HOOK-UP

1. **Water Inlet** - Fitting is a 1/4" SAE male flare located at the rear of the unit. Connect water supply with a 1/4" or larger copper or flexible tubing.
2. **Water Pressure** - Unless otherwise specified, the unit is designed to operate on water pressures between 10 P.S.I. and 90 P.S.I. (NOTE: for pressures above 90 P.S.I. a regulator must be installed).
3. **Water Cooled Condensers**
 - A. Inlet to modulating valve uses 3/8" FPT. Use separate 3/8" or larger water line.
 - B. Outlet is 3/8" FPT.
4. **Filter** - Filter Conditioner is recommended on supply lines to ice makers. Never run the water supply to water cooled Condenser through Filter/Conditioner, it uses up the cartridge unnecessarily and a saturated cartridge can starve the ice maker causing premature component damage. Separate water supplies are recommended.

NOTE: Unit must be installed per local plumbing code.



ELECTRICAL SUPPLY

1. **Power Access** - Is provided by way of a 7/8" dia. hole in both the base and the rear panel. Route incoming power in conduit to ice maker electrical control box. Make connections to wires provided in control box and ground lug/screw. Plug unused hole.

For IMD600-30A and IMD300-30A units, 8 feet, 2 inch long power cord with 3 prong plug attached to the unit.

2. **Fused Line** - Should be a dedicated circuit checked and sized according to electrical rating shown on unit nameplate.

NOTE: Unit must be installed per local electrical code.

DRAIN CONNECTION

1. Install splash panel on machine and hold in place with (2) screws. Do not tighten at this time.
2. Remove drain tray mounting bracket from shipping carton.
3. Clip the drain tray mounting bracket onto the bottom of the splash panel on the brackets provided.
4. Hook the drain tray into the splash panel and onto the mounting bracket.
5. Push the drain elbow securely onto the drain tray. Do not glue in place.
6. Complete drain hookup according to the instructions provided with unit.

NOTE: Steps 7 and 8 to be completed only after all start up checks and adjustments are performed.

7. Replace side panels tightening all (6) screws (including splash panel screws left loose).
8. Replace top panel and front cover and secure with (2) screws.

NOTE: In those cases where the unit is base mounted and not on legs it should be sealed all around the base with NSF listed sealant (P/N 04815-B).

AUGER ENGAGEMENT

Be certain that auger is fully engaged to lower drive and that extruding head is fully engaged to evaporator.

INITIAL START UP, CHECKS & ADJUSTMENT INSTRUCTIONS

NOTE: Do not start unit before completing above Installation Instructions.

Turn on water supply and main power switch (located on top of electric box). All IMD 30 lb. and 90 lb. series units are equipped with a 45 second delay timer. This means that the refrigeration system will not start until 45 seconds of dispense are accumulated in the timer. Start the refrigeration system by depressing the ice dispense button for 45 seconds. Make the following system checks:

NOTE: If unit will not start be sure water reservoir is full. Low water safety control must be properly adjusted to start and shut down unit. If water level drops below bottom of reservoir, unit must shut down. Adjustment is made by moving magnet up or down.

Water Level - If necessary, adjust float by bending float arm up or down as needed. Push float assembly down until unit stops running. Release float and unit will restart. Keep water in reservoir at level line while unit is in operation. See Figure 4.




Figure 4. Float Assembly

Low Water Safety Control - Adjust magnet by bending magnet arm as shown in Figure 4 to shut down unit if the water level drops below the line on the side of the reservoir.

Bin Control - Remove four screws from top of bin cover and lift cover so bin control plate can be manually lifted until unit shuts down. Release plate and unit will restart (on IMD300-30, IMD600-30, and IMD600-90 the dispense button must be depressed for 45 seconds before unit will start). Replace screws.

Dispense Switch and Mechanism - By depressing the dispense switch, the dispense mechanism door on the storage bin will open, and chain, sprockets, and agitator will rotate counterclockwise.

NOTE: If any of these checks or adjustments cannot be achieved, refer to Troubleshooting Section of this manual or call our Technical Support Center for assistance at 1-800-238-3600.

GUIDE TO SERVICE

ICE MAKER CLEANING AND SANITIZING PROCEDURES

Do not use any of the ice made during cleaning operations.

Clean and sanitize ice storage area when cleaning ice maker.



WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Shut off water supply.
2. Remove ice from storage bin.
3. Mix approved cleaner (2 gallons as directed). **Recommended cleaner:** Calgon Corp. of Virginia Chemicals, ice machine cleaner. **Mixture:** 3-1/3 ounces per gallon of water. Do not use nickel safe cleaners.
4. Turn machine on and add cleaner solution to water level control (float reservoir) until 2 gallons have been used.
5. Turn on water supply and run machine for 15 minutes.
6. Turn off machine and remove and discard all ice.
7. Sanitize using household liquid bleach (50 ppm chlorine). **Mixture:** 1 fluid ounce per gallon room temperature water. 2 minute exposure time.
8. Sanitize pre-cleaned inside areas of storage bin liner, door frame, door, as well as exposed surfaces of the evaporator assembly and bin shutoff assembly with sanitizing solution and allow to air dry.

MAINTENANCE

Preventive maintenance can increase the trouble free life of your ice maker. Many authorized service agencies offer service contracts for your ice maker. Contact your local distributor for further information.

Monthly

1. Clean the condenser. Use a brush, vacuum cleaner or blow from inside with air or CO₂ gas. If unit is provided with an air filter, clean or replace.
2. Inspect water feed reservoir at least once a month until a definite pattern for cleaning and sanitizing has been established.

Quarterly

This is the maximum period of time between cleaning and sanitizing the ice maker. In addition to recommended monthly procedure, and if a more frequent cleaning and sanitizing pattern has not been established, unit must be cleaned and sanitized.

Semi-Annually

Semi-Annually in addition to all previously established service procedures perform the following:

1. Check for water leaks in tube connections, water fittings, and lower ice maker water seal.
2. Check drain tubes for clogs and “aged” tubes. Replace if tubes are stained or brittle.
3. Check for signs of condensation. Clean where necessary and replace insulation properly.
4. Check safety circuits for proper operation.
5. Check refrigeration system.
6. Check unit for abnormal noise. Tighten machine and cabinet screws, if necessary.
7. Check white upper bearings on auger assembly. If bearings are less than 1/16” thick, replace. See Figure 5.




Figure 5. Upper Bearing and Auger Assembly

NOTE: Preventive maintenance can increase the trouble-free life of your ice maker. Failure to perform preventive maintenance could void your equipment warranty.

WATER LEVEL CONTROL

HOW WATER LEVEL CONTROL WORKS

When water is introduced through the inlet fitting the float rises. The float pushes against a lever which in turn forces the poppet assembly against the inlet fitting valve seat which seals the water off, (see Figure 4). Before the water inlet is sealed the safety switch is operated. In the event of a water failure the float would drop down and operate the safety switch to shut off the machine.

If water level control will not shut off and seal at level as indicated, be sure inlet pressure does not exceed recommended factory operating range.

Under ordinary circumstances adjustment should not be necessary providing it was properly adjusted when unit was installed or relocated. If, however, the control becomes inoperative, repair or replace. See Start-Up Adjustment.

PURPOSE OF WATER LEVEL CONTROL

1. To automatically maintain proper water level in the evaporator when unit is running and making ice.
2. A safety switch is operated in the event of an interruption in water supply. The switch shuts off the electrical power to the ice maker and its refrigeration system. Switch will reset as soon as cause of water failure has been corrected and proper water level in ice maker has again been reached.
3. The transparent bowl not only provides a visible check of water level, but also is a good guide to the internal conditions which exist within the ice maker assembly itself. (See Cleaning Procedure).

TO REPLACE WATER LEVEL CONTROL



WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Shut off the water supply.
2. Remove the flexible tubing from bottom of water level control and drain water from water level control and evaporator.
3. Remove flexible tubing at bottom of water level bowl connected to the overflow.
4. Hold water inlet fitting with proper tool to prevent it from rotating when disconnecting the water inlet.
5. Remove wing nut holding water control to its mounting bracket. Control can be removed by lifting straight up.

TO REPLACE WATER LEVEL SAFETY SWITCH



WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Unplug Molex connector connecting switch to electrical box.
2. Remove the 2 screws anchoring the water level safety switch to the bottom of the water level control mounting bracket.

ICE LEVEL CONTROL

The ice level control assembly is secured to the top of the ice storage container cover. The cover is secured to the storage container with four screws. The level control switch is operated by a plate assembly located beneath the diaphragm. When the plate assembly is down due to lack of ice in storage container, electrical impulse is sent to compressor, starting the ice making cycle. As ice level increases in storage container, the plate assembly is pushed up. When storage container is full, it de-actuates the switch, stopping the compressor and ice making cycle.

The operating positions of the switch are fixed, no adjustments are necessary. If switch replacement becomes necessary, simply disconnect cable at connector, remove wires from switch.

REFRIGERATION SYSTEM ADJUSTMENTS

A complete understanding of the ice maker and hermetic refrigeration system is necessary before any adjustments are made. The refrigeration technician must use high and low side pressure readings, water, and air temperatures, plus general conditions of cleanliness to assess the refrigeration system status when making any adjustments.

All ice maker products are tested and adjusted at the factory prior to shipment where the ambient temperature ranges from 65°F to 90°F, depending on the season of the year.

Whenever a new ice maker is initially installed and started-up, it is imperative that the start-up operator make the following checks and readjustments for local conditions.

Expansion Valve

You will find a thermal expansion valve on ice makers, which is used to control the amount of refrigerant flowing through the evaporator. Improperly installed or defective expansion valves may cause low production, soft ice, squeaking from evaporator and excessive load inside evaporator.

By using general refrigeration troubleshooting along with the pressure charts (refer pressure chart on page 15), you can easily determine whether or not the expansion valve is working properly.

ADJUSTMENT AND TROUBLESHOOTING

When troubleshooting the expansion valve, you must:

1. Be sure you have adequate water flowing into the evaporator, a clean and properly ventilated condenser, and the system is properly charged and free of any restrictions. Also be sure compressor is operating properly.
2. Take reservoir water temperature and air temperature from condenser inlet and determine at what pressure unit should be running. On machines equipped with thermostatic valve there is NO adjustment. If correct pressure cannot be obtained, be sure system has time to stabilize, 10-15 minutes.
3. Be sure sensing bulb is located at outlet side of evaporator about 3-4 inches away from evaporator and be sure to insulate well and clamp tightly to tubing. If system pressures are still not adequate, take a second water and air temperature reading and go over other parts of the system for possible problems. If proper charge is questionable evacuate and recharge to nameplate and leak check. If valve still malfunctions replace valve.

Use general refrigeration system practices when replacing and recharging unit. After new valve is in place, go through previous monitored adjustments and troubleshooting to be sure valve is functioning properly.

NOTE: On water cooled units adjust condenser modulating valve before troubleshooting expansion valve.



CAUTION:

Very high discharge pressure is present in system. Quick disconnects on your gages will minimize Danger and loss of refrigerant. Comply with federal regulations for reclaiming refrigerant. Condenser Modulating Valve

CONDENSER MODULATING VALVE REMOVAL

The reason for using a water modulating valve is to supply the correct amount of water to the condenser to maintain the proper operating pressure in the refrigeration system high side. The flow of water through the valve is increased as the high side pressure rises and decreases as high side pressure lowers.

To calibrate the amount of water flow with the refrigeration system high side pressure, turn adjustment screw located on end of valve opposite of bellows (see Figure 6). Turn screw counterclockwise to raise opening point. Opening point of valve should be set to maintain proper operating pressure in refrigeration system high side, refer to pressure chart on page 15. Closing point of valve should be set low enough to close valve during compressor stand by periods.

NOTE: Cold water will absorb more heat faster than warm water. The water flow will therefore automatically increase as inlet temperature increase.




Figure 6. Adjustment Screw

WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Shut off water supply to condenser and reclaim refrigerant from system.
2. Remove inlet water line from Condenser Modulating Valve. Also remove tube from refrigerant high side line.
3. Remove Condenser Modulating Valve and bracket.
4. Remove valve from bracket.
5. Replace Condenser Modulating Valve by reversing Steps 2 thru 4.
6. Recharge unit with refrigerant per nameplate.
7. Turn power and water ON to unit.
8. With unit running adjust modulating valve to proper setting.
9. Go through a complete system check.

GEAR MOTOR

The gear motor is equipped with a start relay and a manual reset overload. When current is applied, the relay energizes and completes the circuit to the start winding. The motor reaches a predetermined speed and the relay drops out, disconnecting the start winding. The run winding remains in the circuit as long as current is applied.

The purpose of the overload is to automatically shut off the motor in the event of a mechanical bind of the transmission, an overload condition within the evaporator or an electrical malfunction. It does this by sensing amperage draw. If the motor stalls the start relay would energize and stay energized. The amperage would surge to 5 to 6 times greater than normal draw. In this event the overload would shut off the transmission in 4 to 8 seconds.

If the motor is subjected to an abnormal load, but does not reach stall condition, the overload will react, but over a greater period of time. The reaction time depends upon the amperage to which it is subjected.

The overload, through the safety circuit, also shuts off the compressor.

Refer to Troubleshooting Guide.




Figure 7. IMD 300 Shaft Seal




Figure 8. Auger and Extruding Head Removal

SHAFT SEAL INSTALLATION AND REPLACEMENT

1. Place shaft seal locator seat over gear motor output shaft, embossed side down, and push down until shaft seal seat rests flush on top of gear motor.
2. Place rubber coated ceramic seal (important: ceramic face up) over output shaft and push down until seal rests on top of the shaft seal seat. (Lubricate rubber on ceramic seal with [#06195] rubber lubricant.)
3. Place shaft seal with carbon face down (spring up) over output shaft and push (gently) downward until seal rests on carbon face of output shaft seal.
4. Push down on the washer compressing the spring on the output shaft seal. While holding the seals (down) in place slide the E-Ring into the groove on the output shaft.

AUGER & EXTRUDING HEAD REMOVAL

WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Remove storage container cover and put aside.
2. Turn off water supply to ice maker.
3. After ice has melted from head take hold of the auger nut and lift straight up to disengage from ice maker.
4. When replacing the auger assembly, make certain that both the auger engages the output shaft drive and the extruding head ribs engage the evaporator tube collar. See Figure 8.




Figure 9. IMD 600 Shaft Seal

INSTALLATION AND SHAFT SEAL REPLACEMENT

1. Place shaft seal locator seat over gear motor output shaft, embossed side down, and push down until shaft seal seat rests flush on top of gear motor.
2. Place rubber coated ceramic seal (important: ceramic face up) over output shaft and push down until seal rests on top of the shaft seal seat. (Lubricate rubber on ceramic seal with [#06195] rubber lubricant.)
3. Place shaft seal with carbon face down (spring up) over output shaft and push (gently) downward until seal rests on carbon face of the output shaft seal.
4. Place flat washer over output shaft and let rest on the output shaft seal. Push down on the washer compressing the spring on the output shaft seal. While holding the seals (down) in place slide the E-ring into the groove on the output shaft.

UPPER NUT AND BEARINGS

The upper bearings located on top of the auger is used to absorb the force between the auger and extruding head.

The bearings are 3/32" thick. When they wear below 1/16" they should be replaced. Bearings to be inspected for wear during quarterly maintenance. See Figure 8.

TO REPLACE BEARINGS



WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Dispense all ice from unit.
2. Remove panels.
3. Unplug Dispense Motor and Ice Level Switch.
4. Remove four screws holding dispense cover in place.
5. Remove dispense cover assembly.
6. Use an open end wrench on auger nut connected to bearing and turn counterclockwise to remove assembly.
7. Remove worn bearings. Replace with new bearings and then reinstall assembly.

NOTE: If auger turns with nut, remove cover on top of gear motor stator and hold rotor while loosening nut.

8. Reconnect power to ice maker.

TROUBLESHOOTING COMPRESSOR

Basically the compressor problems can be narrowed down to three areas of checkout.

1. THE COMPRESSOR WILL NOT RUN

- No voltage to the compressor terminals - check circuit.
- Low voltage - below 90% of nameplate rated voltage.
- Problems in the compressor electrical circuit. See Electrical Checkout Instructions.

2. THE COMPRESSOR STARTS BUT TRIPS REPEATEDLY ON THE OVERLOAD PROTECTOR

- Check for proper fan operation and clean condenser.
- Check the compressor suction and discharge pressures.
- Voltage - The voltage should be within 10% of the rated nameplate voltage.
- High compressor amperage draw, it should never exceed 120% of the rated nameplate amperage. See Electrical Checkout Instructions.

3. THE COMPRESSOR RUNS BUT WILL NOT REFRIGERATE

- Check the compressor suction and discharge pressures.

Table 1. Pressure temperature chart

	IMD 300-30			IMD 600-30		
	70°F 50% RH	90°F 65% RH	104°F 65% RH	70°F 50% RH	90°F 65% RH	104°F 65% RH
Discharge Temperature (°F)	180	202	225	195	213	232
Suction Temperature (°F)	29	43	49	29	38	45
Discharge Pressure (psig)	220	280	338	236	306	365
Suction Pressure (psig)	23	26	30	25	28	33
Current (Amps)	7.5	8	8.5	11	12	13

ELECTRICAL CHECKOUT

1. Be sure the unit is disconnected from the power source. Remove the compressor electrical box cover. Check for obvious damage and loose wires.

2. Disconnect the fan motor leads. Since capacitors store energy, short the capacitor with a screwdriver. This will prevent shocks.
3. Disconnect the compressor terminal wires.




Figure 10. Overload Check




Figure 11. Compressor Check

OVERLOAD CHECK

Using a volt-ohm meter check the continuity across the overload, contacts #1 & #3. If none, wait for unit to cool down and try again. If still no continuity, the overload protector is defective and should be replaced.

COMPRESSOR CHECK

The resistance readings on the windings will be between 0.25 and 10.00 ohms, a meter capable of these low readings must be used.

1. Check between "C" & "R". Replace compressor if there is no continuity as the run windings are open.
2. Check between "C" & "S". Replace the compressor if there is no continuity as the start windings are open.
3. Check between "C" & "R", or "S" and shell of the compressor. If there is continuity replace the compressor as the motor is grounded.
4. Check between screw terminal on the overload and "C" on the compressor. Check and repair the lead or connections if there is no continuity.

CAPACITOR CHECK

1. Check or replace start capacitor, disconnect bleed resistor before checking for shorted capacitor.
2. Check or replace run capacitor (if supplied), check for shorted capacitor or either terminal grounded to case.

TROUBLESHOOTING GEAR MOTORS

Basically, gear motor problems can be narrowed down to three areas of checkout.

The Gear motor will not run

1. No voltage to the transmission terminals - check external circuit.
2. Low voltage - check supply.
3. Problems in the gear motor electrical circuit. See Figure 12.

The Gear motor Starts but Trips Repeatedly on the Overload Protector

1. Voltage - high or low voltage can cause the overload to trip.
2. High gear motor amperage draw, see Specification Chart for ratings and Troubleshooting Guide.

The Motor Runs but Output Shaft does not Rotate

Replace defective gear motor.



CAUTION:

Be sure unit is disconnected from the power source. Disconnect the transmission cable.

OVERLOAD CHECK

1. Allow motor to cool and reset overload if necessary.
2. Remove motor end bell and stator, if necessary.
3. Check terminals 1 and 3 on overload. No continuity replace overload. Use a volt-ohm meter. See Figure 10 and Figure 11.

NOTE: Gear motor and related components can be checked from Pin Connector. See Figure 12.

MOTOR CHECK

The resistance readings on the windings will be between 5 to 25 ohms. A meter capable of these low readings must be used. The Start Relay cover must be removed.

If no continuity on start or run winding test, replace stator. If continuity on grounded motor test, replace stator.




Figure 12. Pin Numbers.

SAFETY CONTROLS

Your Ice maker unit has several safety and control devices incorporated into its design.

**WARNING:**

None of the below described devices should ever be “bypassed” to allow the unit to function.

The safety and control system shut-off devices are:




Figure 13. Gear Motor warning

1. Gear motor thermal overload, manual reset type (red button on motor). See Figure 13.
2. Main service switch located on top of the control box.
3. Low water shut off reed switch located in ice maker float assembly (Automatic reset type).
4. Compressor thermal overload, automatic reset type.
5. Hopper shut-off.
6. High pressure cut out (water cooled only).

**WARNING:**

Do not reset gear motor overload if ice is present in the evaporator.

GUIDE TO GOOD ICE

CUSTOMER COMMENTS	CHECK ICEMAKER LOCATION CONDITIONS FIRST	CHECK ICEMAKER
"It runs but the ice is too soft."	• Proper air flow for condensing system.	• Use gauges for checking suction and head pressures. See manual for correct reading and conditions. Check frost line and sight glass.
"The icemaker is not producing enough ice."	• Location too close to hot units such as coffee urns, deep fryers, grills, etc. • Supply water conditions.	• Check water level for proper adjustment and restrictions. See Page 7.
"The ice is too wet."	Water too warm (above 90°F). Water artificially softened above 262 ppm sodium chloride. Normal water supply too high in total dissolved solids (above 500 PPM).	• Check evaporator assembly for worn parts, bearings, scored evaporator and auger, bad expansion valve, etc.
OVER COMPRESSION		
"It makes too much noise." (With this comment the ice is usually extremely hard and larger than normal.)	• Check to see if noise objection is normal fan and air flow noise. • Supply water conditions. Water too cold (below 50°F). (Possibly running from pre-cooler.) • Obstructions partially blocking ice exit from top of evaporator. • Check fan and fan shroud.	• Check for loose parts and screws rattling. • Check evaporator assembly for worn parts, bearings, scored evaporator and auger, bad expansion valve, etc.

SCHEMATICS




Figure 14. Component Interconnection Schematic






Figure 16. . Schematic IMD 300-15




Figure 17. Schematic IMD 300-30, IMD 600-30, IMD 601-30, IMD 600-90 and IMD 601-90




Figure 18. Schematic IMD 302-30, IMD 602-30 and IMD 602-90

Cornelius Inc.
www.cornelius.com