



## AUTOMATIC CREW SERVE DISPENSER

### Preventative Maintenance and Cleaning



**Daily**

#### Nozzle and Diffuser

- Rotate the nozzle clockwise and pull down to remove it.
- Pull down on diffuser to remove.
- Clean with valve brush and sanitize.



*First, stop dispenser by pushing **Manual Mode button**.*

*When washing, do not soak gasket more than 2 minutes.*

**Daily**

#### Drip Tray

- Flush with soap solution and warm water.
- Clean surfaces with cloth and sanitize.
- Ensure water deflector gasket is in place before re-installing carousel.
- Align drive shaft on left side to re-install conveyor.



*See Operator's Manual for further instructions and safety information.*




*Watch the Preventative Maintenance and Cleaning Video for complete steps.*

**Daily**

#### Cup Carousel

- Loosen the two thumb-screws to remove the carousel cover.
- Remove carousel, drain guard, and grill.
- Clean and sanitize all removed parts.



*Never place any parts in dishwasher.*

**Weekly**

#### Exterior

- Wipe cup dropper cover, backsplash, side walls, and top exterior panels.
- Wipe touch screen with clean, moistened cloth.
- Use Cleaning Lockout feature in service menu to prevent inadvertent button presses during cleaning.

*Do not clean the touchscreen with solvents or cleaning agents.*