



AUTOMATIC CREW SERVE DISPENSER

How to Refill Ice manually Out of Ice?



Step 1

Lift the ice loader lid handle to swing up and forward to open.

- Unit will still be functional during this process.
- The lid must cover the display.



Step 2

Ensure the lid covers the display.

- Be sure to use the right type of ice.
- Do NOT hang on the ice loader.



Step 3

Place the bucket on the ice loader and slowly raise until empty.

Note: Allow ice to flow into the hopper, do not dump the whole bucket together.



Step 4

Lift and raise the ice loader lid to close.

- Clean any spilled ice on the lid.
- Using a clean microfiber cloth Wipe any moisture on the display screen.



To ensure consistent ice dispense and beverage fill levels, keep the hopper at least half full.