



PRISM

Owner's Manual



Release Date: September 25, 2018

Publication Number: 548000096

Revision Date: September 5, 2025

Revision: J



Marmon Foodservice
Technologies

A Berkshire Hathaway Company

Visit the Cornelius web site at www.cornelius.com for all your Literature needs.

NOTICE

The products, technical information, and instructions contained in this manual are subject to change without notice. These instructions are not intended to cover all details or variations of the equipment, nor to provide for every possible contingency in the installation, operation or maintenance of this equipment. This manual assumes that the person(s) working on the equipment have been trained and are skilled in working with electrical, plumbing, pneumatic, and mechanical equipment. It is assumed that appropriate safety precautions are taken and that all local safety and construction requirements are being met, in addition to the information contained in this manual.

This Product is warranted only as provided in Cornelius' Commercial Warranty applicable to this Product and is subject to all of the restrictions and limitations contained in the Commercial Warranty.

Cornelius will not be responsible for any repair, replacement or other service required by or loss or damage resulting from any of the following occurrences, including but not limited to, (1) other than normal and proper use and normal service conditions with respect to the Product, (2) improper voltage, (3) inadequate wiring, (4) abuse, (5) accident, (6) alteration, (7) misuse, (8) neglect, (9) unauthorized repair or the failure to utilize suitably qualified and trained persons to perform service and/or repair of the Product, (10) improper cleaning, (11) failure to follow installation, operating, cleaning or maintenance instructions, (12) use of "non-authorized" parts (i.e., parts that are not 100% compatible with the Product) which use voids the entire warranty, (13) Product parts in contact with water or the product dispensed which are adversely impacted by changes in liquid scale or chemical composition.

Correct Disposal of this Product



RECYCLE

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Trademarks and Copyrights

This document contains proprietary information and it may not be reproduced in any way without permission from Marmon FoodService Technologies Inc. This document contains the original instructions for the unit described.

MARMON FOODSERVICE TECHNOLOGIES INC

355 Kehoe Blvd

Carol Stream, IL

Tel: + 1 800-238-3600

Printed in U.S.

Contact Information

To inquire about current revisions of any documentation or assistance with any Cornelius product, contact:

www.marmonfoodservice.com

www.cornelius.com

800-238-3600



TABLE OF CONTENTS

Safety Instructions	1
Read and Follow all Safety Instructions	1
Safety Overview	1
Recognition	1
Different Types of Alerts	1
Safety Tips	1
Qualified Service Personnel	2
Safety Precautions	2
Operation	3
Prism	3
Optifill	3
Sanitary Lever	3
Push Button	3
Cleaning Instruction	4
Daily Cleaning	4
User Instruction	4
How to Check Prism Ratio	6
How to Program Optifill Top Off	8
Disable Optifill Top-Off Delay	9
How to Program Portion Control Sizes & Top Off	10
Programming the Portion Sizes	10
Programming a TopOff Pour	11
Restoring Default Time Valves	13
Adjusting Valve Flow Rates Values	15
Knock Out Kit	16
Knock Out Punch Instructions	18
Installation Instructions	20
Knock Out Adapter Plate	20
Knock Out Adapter Plate and Tubing	20
Installation Kit	21
Back Block Installation	22
Valve Installation	24
Locking Valve with Back Block Using Lock Pin	26
Connection Diagram	27
Syrup and Water Maps	28
Touch Module and Cover Installation	29
Schematics	30
Plumbing Diagram	30
Wiring Diagram	31
Illustrated Parts List	32
Valve Assembly	32
Prism Decal	35


SAFETY INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

Safety Overview

- Read and follow ALL SAFETY INSTRUCTIONS in this manual and any warning/caution labels on the unit (decals, labels or laminated cards).
- Read and understand ALL applicable OSHA (Occupational Safety and Health Administration) safety regulations before operating this unit.
- Must wear required PPE before you start to service or maintain the equipment.

Recognition

<i>Recognize Safety Alerts</i>
<div style="text-align: center;"><p><i>This is the safety alert symbol. When you see it in this manual or on the unit, be alert to the potential of personal injury or damage to the unit.</i></p></div>

DIFFERENT TYPES OF ALERTS



DANGER:

Indicates an immediate hazardous situation which if not avoided WILL result in serious injury, death or equipment damage.



WARNING:

Indicates a potentially hazardous situation which, if not avoided, COULD result in serious injury, death, or equipment damage.



CAUTION:

Indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury or equipment damage.

SAFETY TIPS

- Carefully read and follow all safety messages in this manual and safety signs on the unit.
- Keep safety signs in good condition and replace missing or damaged items.
- Learn how to operate the unit and how to use the controls properly.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Keep your unit in proper working condition and do not allow unauthorized modifications to the unit.
- Any modifications to be done by Factory Authorized Service personnel only.
- Any part replacement in the system shall be conducted with like components.

QUALIFIED SERVICE PERSONNEL



WARNING:

Only authorized service personnel shall service the valve. ALL WIRING AND PLUMBING MUST CONFORM TO NATIONAL AND LOCAL CODES. FAILURE TO COMPLY COULD RESULT IN SERIOUS INJURY, DEATH OR EQUIPMENT DAMAGE.

SAFETY PRECAUTIONS

This unit has been specifically designed to provide protection against personal injury. To ensure continued protection observe the following:



WARNING:

Disconnect power to the unit before servicing following all lock out/tag out procedures established by the user. Verify all of the power is off to the unit before any work is performed.

Failure to disconnect the power could result in serious injury, death or equipment damage.



CAUTION:


Always be sure to keep area around the valve clean and free of clutter.

Failure to keep this area clean may result in injury or equipment damage.

OPERATION

PRISM

FRONT COVER



REAR VIEW

Figure 1.

The Cornelius Prism is capable of dispensing 3 CARBONATED BRANDS / SYRUP OR 3 NON CARBONATED BRANDS / SYRUP and comes with 3 variants as below, refer Table 1 on page 4.

NOTE: Both carbonated and non carbonated beverages CANNOT BE DISPENCED IN THE SAME VALVE

Optifill

The user places a cup against the dispensing lever, press the brand, and the valve automatically shuts off after the cup begins to overflow.

Sanitary Lever

The user manually dispenses a beverage by selecting a brand and then pressing the cup against the dispensing lever.

Push Button

The user manually dispenses a beverage by pressing the brand until the cup is full.

Portion Control

The user dispenses a beverage by pressing the brand button, then pressing a cup size button, and then the valve automatically dispenses for a fixed time. Times are programmable, with the option to add top-off.

Table 1

Part No.	Description
Sanitary Lever Valves	
620073003	Prism, Ceramic regulator, with mounting block and covers
Push Button Valves	
620073005	Prism, Ceramic regulator, with mounting block and covers
Optifill Lever Valves	
620073007	Prism, Ceramic regulator, with mounting block and covers
Portion Control Valves	
620069306	Prism, Ceramic regulator, with mounting block and covers

CLEANING INSTRUCTION

Daily Cleaning

1. Remove nozzle and diffuser from the valve and clean with warm soapy water. Soak with sanitization with 2-3 minutes and Rinse with clean water, reinstall them back onto the valves and allow to air dry.




Figure 2.

2. Wash external surfaces with mild soap solution, rinse with clean water, and wipe dry.

NOTE: While cleaning the valve do not use abrasive or harsh cleaners on the unit.

NOTE: Diffuser is only compatible with Prism valve.



CAUTION:

All sanitizing solution must be drained from the system. A freezing ambient environment will cause residual sanitizing solution or water remaining inside the valve to freeze resulting in damage to internal components.

SETUP INSTRUCTION

During this step, pour directly from the valve into the ratio cup. Pour water & syrup separately

3. Enter into "brix mode" by adjusting the valve dip switch. Set the dip switches as shown in Figure 4. Press and release the water button. The valve will dispense a preset amount of water. Adjust the flow rate using the valve flow control until the flow rate is adjusted properly. After water is adjusted properly - use the syrup buttons to dispense a preset amount of syrup. Adjust the corresponding syrup flow control until the syrup flow rate is adjusted properly.




Figure 3.




Figure 4.

NOTE: The switch is located in the upper right hand corner of the back of the valve faceplate.




HOW TO CHECK PRISM RATIO





CAUTION:

Do not expose the capacitive touch module wire to water.

Table 2.

Step	Action	Figure
1.	Remove the capacitive touch module by lifting it upward and pulling out. Remove the rear valve cover. Leave the wire attached to the capacitive touch module.	 <p>Figure 5.</p>
2.	Place the ratio cup under the valve.	
3.	Place the dip switch into "brix mode".	 <p>Figure 6.</p>
4.	<p>Press the water button to activate a time dispense of 4.0 sec. Target 10oz into the water chamber of the ratio cup.</p> <p>NOTE: After the water flow is adjusted, note the level of the ratio cup. Do not adjust the water again for the syrup.</p>	 <p>Figure 7.</p>

<p>5.</p>	<p>Press a brand to activate the time dispense into the proper syrup chamber. If the syrup level doesn't fall within one bandwidth from the noted water level, turn the adjust screw on the appropriate syrup flow control counterclockwise to decrease syrup flow or clockwise to increase syrup flow. Dispense a few drinks to check the ratio. Re-adjust as necessary. Repeat for the remaining flavors.</p>	 <p>Top View</p> <p>Figure 8.</p>
<p>6.</p>	<p>Select the respective mode based on the type of dispense.</p> <p><u>After selecting the appropriate dispense mode, power cycle the valve by disconnecting and reconnecting the water connector.</u></p>	 <p>Figure 9.</p>
<p>7.</p>	<p>Replace the rear valve cover and replace the capacitive touch module.</p>	


HOW TO PROGRAM OPTIFILL TOP OFF



WARNING:
Do not expose the capacitive touch module wire to water


Programming Top-Off Delay

Table 3.

Step	Action	Figure
1.	<p>Set the Dip Switch to Optifill mode as shown in Fig. 10</p> <p>Enter into “Program mode” by pressing the program button, located in the bottom-right corner of the front cover, for 3 seconds until the LED light turns on.</p> <p>Important: If power to the valves is turned off while programming, perform a factory reset of the valve after power is restored (See “Restoring Default Time Values” section) After the reset, program the valve as intended.</p>	 <p>Figure 10.</p>
2.	<p>Press and release a desired Brand button.</p> <p>Place cup against the lever to allow the valve to begin dispensing. When the foam or liquid touches the lever the valve will automatically stop. This is the initial pour. The cup must remain in place with the lever pressed. The LED light will flash at this time.</p>	
3.	<p>When the foam in the cup has lowered, press and release the desired brand button. The valve will begin dispensing and will stop when the foam or liquid touches the lever. This is the top-off pour. The time between the end of the initial pour and when the pour is re-started is the top-off delay, which is now stored in the PC board. The LED light will be on steady (no flash) at this time.</p>	
4.	<p>When finished, program additional top-offs by repeating step 2 & 3, or exit out of “Program mode” by pressing the program button, located in the bottom-right corner of the front cover, for 3 seconds until the LED light turns off.</p>	

DISABLE OPTIFILL TOP-OFF DELAY

Table 4.

Step	Action	Figure
1.	Enter into "Program mode" by pressing the program button, located in the bottom-right corner of the front cover, for 3 seconds until the LED light turns on. Important: If power to the valves is turned off while programming, perform a factory reset of the valve after power is restored (See "Restoring Default Time Values" section) After the reset, program the valve as intended.	 <p>Location of Program Button</p> <p>Keep cup against lever until liquid touches lever</p> <p>Figure 11.</p>
2.	Press and release a desired Brand button. Place cup against the lever to allow the valve to begin dispensing. When the foam or liquid touches the lever the valve will automatically stop.	
3.	Remove the cup from against the lever. This will enter a zero value for the "top-off" delay time and disable a top-off pour.	
4.	When finished, exit out of "Program mode" by pressing the program button, located in the bottom-right corner of the front cover, for 3 seconds until the LED light turns off.	

HOW TO PROGRAM PORTION CONTROL SIZES & TOP-OFF



WARNING:

Do not expose the capacitive touch module wire to water.

Note: If the “cancel/pour” button is held pouring for more than 30 s, the pour times out and stops flow. The pour button must be released and re-pressed to resume flow.

Default Time Settings

The Prism valve Portion Controls are factory programmed with time values that can be useful during initial installation and for testing the modules. The time values for each portion size are shown in the following table.

Portion Size	Initial Pour Size
Small “S”	2s
Medium “M”	3s
Large “L”	4s
Extra Large “XL”	6s

Programming the Portion Sizes

Note: It is recommended that when programming portion sizes, use actual cups and ice lever.

Programming a Standard Pour.

Table 5.


1.	Set the Dip Switch to Portion Control mode as shown in Fig. 12 Enter into “Program mode” by pressing the hidden program button at the bottom-right corner of the front cover, for 3 seconds until the LED light turns on. Important: If power to the valve is turned off while programming, perform a factory reset of the valve after power is restored (See “Restoring Default Time Values” section) After the reset, program the valve as intended.	 <p>Portion Control</p>
2.	Press and release a desired Brand button. Press and hold the portion size button until the desired level is reached in the cup; release the button. Portion will be recorded with program mode is exited.	
3.	Continue with other portion size buttons or reset the same portion size again.	


Figure 12.

4.	Program additional brands by repeating step 2 and 3, or when complete, exit the program mode by holding the hidden program button for 3 seconds	
5.	The last portion set for each button is now recorded	

Programming a Top-Off Pour.

Note: It is recommended that when programming a top-off pour, use actual cup and ice level.

Table 6.

1.	<p>Enter into top-off Program mode by pressing the program button (located at the bottom-right corner of the front cover) and “S” together for 3 seconds until the LED light turns on.</p> <p>Note: To avoid accidental pour ensure the program button is depressed slightly earlier then the “S” Button.</p> <p>Important: If power to the valves is turned off while programming, perform a factory reset of the valve after power is restored (See “Restoring Default Time Values” section) After the reset, program the valve as intended.</p>	 <p>The “S” Button (Small Portion size)</p> <p>Location of Program Button</p> <p>Select appropriate Portion Size Button (S,M,L or XL)</p> <p>Figure 13.</p>
2.	<p>Press and release a desired Brand button.</p> <p>Press and hold the portion size button until the desired level is reached in the cup then release the button.</p> <p>Once the foam settles, press the same button again to add a top-off pour. The initial pour, pause, and top-off will be recorded when the program mode is exited</p>	
3.	<p>Continue with other portion size buttons or reset the same portion size again.</p> <p>Note that the two dispenses and pause between them will be saved for each portion size when the top-off program mode is exited.</p>	





4.	Program additional brands by repeating step 2 and 3, or when complete, exit the program mode by holding the hidden program button for 3 seconds	
5.	The last portion, pause and top-off each button is now recorded Note It is possible to have same portion size with a top-off and others without a top-off.	


Restoring Default Time Values.

The factory default standard pour time values can be restored using the following procedure.

Table 7.



<p>1.</p>	<p>Enter into “Program mode” by pressing the program button located at the bottom-right corner of the front cover for 3 seconds until the LED light turns on.</p>	<p>Select the appropriate portion size (S,M,L or XL)</p>  <p>Program Button Location</p> <p>Figure 14.</p>
<p>2.</p>	<p>Press and hold the Cancel/Pour Button.</p>	 <p>Cancel/Pour Button</p> <p>Figure 15.</p>



3.	<p>Press and release a desired Brand button.</p> <p>Press and release the desired portion size button to be reset.</p> <p>The LED light will flash to indicate that the size will be reset.</p>	<div><p>Select the appropriate Portion Size Button (S,M,L or XL)</p></div> <p>Figure 16.</p>
4.	<p>Release the “Cancel/Pour” button. The time valve listed in “Default Time Values” was restored to that size.</p>	
5.	<p>The “Cancel/Pour” Button must be released and re-pressed before resetting another size.</p>	
6.	<p>Program addition brands by repeating steps 2 & 3 ; or when complete, exit the program mode by holding the hidden program button for 2 seconds</p>	

Adjusting Valve Flow Rates Values

Table 9.

Step	Action	Figure
1.	If re-adjusting a valve previously set-up, reset a module portion size button to provide its "Default Time Value ". To do this, refer to "Restoring Default Time Values" section above, then proceed to step 2. Note: If adjusting a valve for the first time, skip to step 2 below.	
2.	Press and release a desired Brand button. Hold cup under valve nozzle and press the portion button..	 <p>Figure 17.</p>
3.	Adjust water/syrup flow control if necessary. Repeat as necessary.	 <p>Figure 18.</p>
4.	When finished adjusting flow rate, remember to reprogram the portion size buttons at the new flow rate.	

Knock Out Kit-P/N 629097803

NOTE: All Enduro Cold Carbonation units since 2004 have panels that will accept the Prism Valve. Models: ED150BCH, 150BCHZ, ED175BCH, ED175BCHZ, ED200BCH, ED200BCHZ, ED250BCH, ED250BCHZ, ED300BCH and ED300BCHZ

NOTE: All Enduro Ambient Carbonation and Beverage Only units prior to November 2018 will require the punch tool, All Enduro Units since November 2018 have panels that will accept the PRISM valve

NOTE: All IDC Units (Serial #: 62C0912JD002) since 2009 have panels that will accept the Prism Valve.

NOTE: All Duraflex units "DF 150/175/200/250" will not accept PRISM valve due to being "hard plumbed".

NOTE: All Drop-in Units since December 2019 have panels that will accept the PRISM valve.

1. CB1522(Six Valves) - Serial #74A1942KD256 and 74A1945KD039.
2. CB1722 and CB2323(Six Valves) -Serial #74A1946KD163.
3. CB2323(Eight Valves)-Serial #74A1939KD193.
4. CB2323(Ten Valves)-Serial #74A1949KD212.
5. CB3023(Ten Valves)-Serial #74A1942KD355





Figure 19.



Knockout kit P/N-629097803

Figure 20.

KNOCK OUT PUNCH INSTRUCTIONS



WARNING:

Must wear required PPE and right tools before using the punch out tool.



WARNING:




Disconnect power to the unit before servicing following all lock out/tag out procedures established by the user. Verify all of the power is off to the unit before any work is performed.







CAUTION:

Disconnect all fluid supply to the unit and release all pressures in the system.

Table 10.

Step	Action	Figure
1.	Remove the valve from the back block.	 <p>Figure 21.</p>
2.	Remove the existing back-block from the valve panel. NOTE: Keep the screws safe for later. NOTE: Used with installation of new "Prism".	 <p>Figure 22.</p>
3.	Load the "Front Die" with "Punch Tool".	 <p>Figure 23.</p>

<p>4.</p>	<p>Align the 2 dowel pins of the “Rear Die” with Corresponding holes on the “Valve mounting panel”.</p>	 <p>Figure 24.</p>
<p>5.</p>	<p>Assemble “Front Die” loaded with “Punch Tool” to “Rear Die”, using 2 Phillip “8-32” screws.</p>	 <p>Figure 25.</p>
<p>6.</p>	<p>Assemble & tighten the hexagon bolt using socket wrench, until the bolt head rests on the front die surface. NOTE: Add lubricant to 3/16” bolt before using the knockout.</p>	 <p>Figure 26.</p>
<p>7.</p>	<p>Remove the tool from the valve mounting panel and dispose of the punched out piece.</p>	 <p>Figure 27.</p>



CAUTION:

NOTE: Position of the punching may vary, depending upon requirement.

NOTE: With reference to Step - 5, all 2 screws must be tightened to avoid any tool damage or improper punching.

INSTALLATION INSTRUCTIONS


KNOCK OUT ADAPTER PLATE - P/N 620069489



.KNOCK OUT ADAPTER PLATE AND TUBING

TABLE 11



1. Align knock out adapter plate with 4 holes of valve mounting panel from "Front Side".



INSTALLATION KIT P/N 629097802

2. Prepare the tubing assemblies.

**Mounting screw
P/N 620700602**



**90° Short
Fittings
P/N 620709068**

**90° Long
Fittings
P/N 620709073**

**Oetiker Clamp
P/N 311908000**




Figure 29.

NOTE: Check the O-rings on the 90° fittings for damage and replace if necessary.

NOTE: Apply Dow 111 or equal lube on the O-rings prior to install.

NOTE: Use P/N 620717792 to order additional Flex tubing

NOTE: Use P/N 629097822 for an advance kit(100' Flex tubing, Barb Fittings & Co2 tubing, O-rings & Oetikers).

Table 5.

A.	Plain/Carb Water	Use 90° short fitting, 1/4" tubing & insulation from existing plain / carbonated Water line
B.	Syrup 1	Existing syrup line from the cold plate
C.	Syrup 2	New syrup line using 90° short fitting & 1/4" insulated tubing
D.	Syrup 3	New syrup line using 90° long fitting & 1/4" insulated tubing







BACK BLOCK INSTALLATION



Figure 30.

Table 12



Step	Action	Figure
1.	Route the wire & connector through relief hole of rear adapter plate and back block.	<div><p>Figure 31.</p><p>Figure 32.</p></div>



<p>2.</p>	<p>Assemble all the lines with L - fittings on to the knock out adapter plate and</p>	 <p>Figure 33.</p>
<p>3.</p>	<p>Align the back block inlet ports to the L- fittings and fasten back block to the valve panel using screws removed earlier (Use either existing screws or screws provided in the kit).</p>	 <p>Figure 34.</p>



VALVE INSTALLATION

TABLE 13.



Step	Action	Figure
1. 2. 3.	Slide, open the capacitive touch module. Disconnect the wires from the capacitive touch module. Remove the rear cover	 <p>Figure 35.</p>
4.	Apply Dow 111 or equal lube on O - rings before assembling the valve body. Align the inlet holes of “valve body” with outlet holes of back block.	 <p>Figure 36.</p>


	<p>5. Gently push the valve body against back block, until rear surface of the valve body is flush with the back block.</p>	 <p>Figure 37.</p>
	<p>6. Lock the valve body and back block together with lock pin. Refer to Table on page 26.</p>	 <p>Figure 38.</p>



LOCKING VALVE WITH BACK BLOCK USING LOCK PIN

TABLE 14

Step	Action	Figure
1.	Align the valve body with back block.	 <p>Figure 39.</p>
2.	Insert the lock pin through the back block and valve body.	 <p>Figure 40.</p>

<p>3. Rotate both the spindles in the direction shown to secure the lock pin in position and also to open the flow path of the drink.</p>	 <p>Figure 41.</p>
---	--

CONNECTION DIAGRAM







Figure 42.

SYRUP AND WATER MAPS

NOTE: For switch positions, refer figure 4 on page 5.



FRONT COVER







REAR VIEW



FRONT VIEW

Figure 43.

TOUCH MODULE AND COVER INSTALLATION

Step	Action	Figure
1.	Assemble rear cover.	 <p>Figure 44.</p>
2.	Route the wires from valve body and connect with capacitive touch module, refer Figure 45.	 <p>Capacitive Touch Module</p> <p>Figure 45.</p>
3.	Slide the touch module on the rear cover from top.	 <p>Figure 46.</p>
4.	Press each button on the capacitive touch module & visually check the pour. NOTE: Refer page 6 for ratio information.	 <p>Figure 47.</p>



SCHEMATICS

PLUMBING DIAGRAM




Figure 48.

WIRING DIAGRAM




Figure 49.

ILLUSTRATED PARTS LIST

VALVE ASSEMBLY




Figure 50.



Item No.	Part No.	Description
1	620069122	Valve Body Assy.
2	620069122-BODY	Valve Body
3	620069122-PLUG	Valve Body Plug
4	620069522	Plate Valve Base
5	620056417	Back Block Assy
	620069515M	Back Block Assy
6	560003252	Lever Valve Optifill
	560003193	Lever Valve Self Serve
7	84996001	Flow Control Bonnet Assy
8	620069310	Screw #8-18 X 1/2 Type 25 410 SS
9	620070153	Plate Retaining Prism Valve
10	71860292	Retainer Ring
11	60245001	Flow Adjustment Screw FFV
12	31525030	O-ring .174 ID 103CS
13	60247	Bonnet FFV Flow Control
14	31525007	O-ring .488 ID 103CS
15	48258005	Spring Syrup
16	60281002	Piston Syrup FFV
17	60281001	Sleeve Syrup FFV
18	740001883	O-Ring
19	60280002	Piston Water FFV
20	48258006	Spring Water
21	620069126W	Water Solenoid Assy
22	740002477	Quad Ring 489ID 070CS 70DU 559PE
23	620069127-302	Front Cover Touch Module Black OP/SL/PB/PC
24	620057622	Screw #8-18 X 3/8
25	620069124	Optifill Probe
26	620073724	Lever Return Spring
27	620069311	Screw #3-24 X 3/8
28	620069584	Micro Switch
28	183184000	O-ring 1.17 ID 103 CS
30	620069283	Diffuser Assy
31	311086000	O-Ring .929 ID 070 CS
32	620069559	Diffuser
33	620069120	O-Ring .551 ID 070 CS
34	620071754	Nozzle Black
35	1950	Cover Valve Black

Item No.	Part No.	Description
36	629097802	Installation Kit (Not shown in Fig.51)
	309852000	Oetker Clamp #11.3 (Not shown in Fig 51)
	620709073	1/4 Dole L Fitting (Not shown in fig 51)
	620709068	1/4 Barb Fittings X1/4 SS (Not shown in fig 51)
	620717791	265 IDX420 Tube (Not shown in fig 51)
	620700602	Mounting Screw (Not shown in fig 51)
37	629097803	Knockout Kit (Not shown in fig 51)
	620069489	Knockout Adapter Plate (Not shown in fig 51)
	620070512	Knockout punch Tool (Not shown in fig 51)
38	620070509	Pepsi Decal (Not shown in fig 51)
	620070510	Generic Decal (Not shown in fig 51)
39	620070715	Portion Control Decal (Not Shown in Fig 51.)

PRISM DECAL:

Table 6

Part number	Description
620070509	Pepsi Decal
620070510	Generic Decal
620070715	Portion Control Decal

Decal dimensions: Per brand




Figure 51.

Marmon Foodservice Technologies Inc.
www.marmonfoodservice.com
www.cornelius.com