

TECHNICAL TIP

Product: Cornelius IDC Pro 255

Subject: SSD Card Change to support software upgrade from 1.x.x to 2.x.x

Date: 01/25/2021

Description of Potential Issue: No potential issue or concern.

Serial Number Range Affected: This change was implemented the 36th week of 2020 on IDC Pro dispenser with SN:62D2036RP001.

Cause: This is a rolling change to support component updates as well as a software upgrade from 1.x.x to 2.x.x to enhance platform security and stability.

Observations: NA

Corrective Action: No corrective actions necessary unless you wish or need to update from 1.x.x to 2.x.x which will require a new SSD card.

Additional Info: Since this is a rolling change, the part number will stay the same, PN: 629097779. Software version 1.11.5 is the latest and last software release for 1.x.x software but it will still be available to support IDC Pro dispensers operating on the 1.x.x platform. A new SSD card will be required to update from 1.x.x to 2.x.x software and you can use configuration backups from 1.x.x to load on to 2.x.x if needed.

Conclusion: *IDC Pro SSD card was changed to support component and software upgrade from 1.x.x to 2.x.x.* This is a rolling change that was implimeted the 36th week of 2020. It is not necessary to upgrade your SSD unless you wish to or need to. It is highly recommended to always have the latest software version for the platform you are running. You can find the latest software releases on our website at www.Cornelius.com as well as the instructions to support changing the SSD card and updating software as needed.